

# Combi-Cam™

**No Need to Keep Track of Keys!!**

## **Instructions for setting your personal combination:**

- The combination is factory set at >>0-0-0-0<<
- Combination must be on opening number prior to resetting
- On the underside outer edge of the lock there is a hole for the code reset button. Rotate the face of cam until the code reset button comes into view.
- Push this pin in with a paper clip **and keep it pushed in**
- Set your personal combination by turning the dials to the desired combination – starting with the dial marked ‘1’, and moving to ‘2’, ‘3’, and then ‘4’.
- Release the reset button and your combination is set.
- To lock, rotate lock to “locked” position. Rotate one or more dials after lock is closed. To open the lock, turn dials to your personal combination.

NOTE: If you desire, the Combi-Cam can be installed such that it is non-resettable by the end-user.

## **Directions:**

- Take off the screw to the cam and remove the cam & the “stop cam”
- Rotate the cylinder 180 degrees and then put the “stop cam” and the cam back on.

Division of

[www.combi-cam.com](http://www.combi-cam.com)

18424 Highway 99

FJM Security Products

Lynnwood, WA 98037

[www.fjmsecurity.com](http://www.fjmsecurity.com)